



Cal. 509,519

INDICATION: During the calendar jump phase between **09.30 pm and 00.00 am** the date can be changed. In this case the date of the following day needs to be set as there will be no jump at midnight.

Stem position 1

– Home position, watch runs

Stem position 2

Quick change of the date (clockwise), watch runs

The date indication consists of a 2-disc system. On each first day of a new month, the date has to be set by quick change from 31 over 39 to 01.

In rare cases, the quick change may be disengaged between 09.30pm and 00.00am (without damaging the movement). In this case the date indication can be reactivated by using the regular hand setting mechanism.

Stem position 3

– Hand-setting, watch stops

– when stem pulled out, save up to 70% energy

Battery

371

Ø 9.50 mm, H 2.10 mm