






FRANCE EBAUCHES

Big date 7331-73310




Pull out the crown in position (3) :

- Turn in (b) direction until date jumping (=midnight).
- Go on turning to set the time - a.m. or p.m.



Put the crown in middle position (2) :

- Turn in (a) direction.
- Set ten figure first, then unit figure.



Push the crown back to position (1) :
working position.

Notice : The date must be corrected at the first day of each month (= see).